


AIR BLOWER SCHEMATICS



AIR BLOWER SCHEMATICS

Parts Listing

Ref. No.	Part No.	Description	QTY
1	81008-001	Conduit Cover Plate, Gasket, 2 Screws, and Wiring Diagram (Kit)	1
2	81006-001	Blower Housing with Foam Inserts (Kit)	1
3	28569-001	Bracket	1
4	67111-001	Gear Clamp	2
5		Motor	1
	81000-001	1 hp 120v	
	81003-001	1 hp 240v	
	81001-001	1-1/2 hp 120v	
	81004-001	1-1/2 hp 240v	
	81002-001	2 hp 120v	
	81005-001	2 hp 240v	
6	15497	Sleeve	1
7	28555-001	Discharge Housing	1
8	67007-001	8-16 x 3/4" Plastite Screw	8
9	10116-001	Check Valve	1

For parts orders or assistance call **(815) 675-7000** or
email customer support at **customersupport@intermatic.com**